

STAR Trigger BCE Crate Layout

run 22

front:

DSM BE015 (0x1E)
DSM BE014 (0x1D)
DSM BE013 (0x1C)
DSM BE012 (0x1B)
DSM BE011 (0x1A)
DSM BE010 (0x19)
DSM BE009 (0x18)
DSM BE008 (0x17)
DSM BE007 (0x16)
DSM BE006 (0x15)
DSM BE005 (0x14)
DSM BE004 (0x13)
DSM BE003 (0x12)
DSM BE002 (0x11)
DSM BE001 (0x10)
STP2C (stp2c-bce:scaler:bnl:local)
RCC2 (0x25)
MVME23006 (bce:trg:bnl:lc)

RCF2:

4A 4B 9A 9B 3A 3B 8A 8B 2A 2B 7A 7B 1A 1B 6A

back:

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21

TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
TDSMI
RCF2

south platform rack 1A7-1