




xlow for bsm dp plane, mod 119




xhigh for bsm dp plane, mod 119




xdiff for bsm dp plane, mod 119




nzero for bsm dp plane, mod 119




rms for bsm dp plane, mod 119



nlow for bsm dp plane, mod 119



slopes for bsm dp plane, mod 119



relative errors for bsm dp plane, mod 119

