




xlow for bsm dp plane, mod 116




xhigh for bsm dp plane, mod 116




xdiff for bsm dp plane, mod 116




nzero for bsm dp plane, mod 116




rms for bsm dp plane, mod 116



nlow for bsm dp plane, mod 116



slopes for bsm dp plane, mod 116



relative errors for bsm dp plane, mod 116

